


Please don't abandon the products as wastes at will.
It should be recycled and disposed separately. Thanks!

WL/CM-03NL(E crust) Network video doorphone system




USER'S MANUAL

(Edition:V1.00)

Instructions for relay equipment wiring


~VM-03N video amplifier

- (1) (Connect VCC,GND terminal with DC12V power's positive and negative polarity respectively
- (2) VFO,GND is one video output, connect with network equipment's TV+, TV- respectively
- (3) VF1~VF3, GND are three video outputs, connect VF1~VF3 terminal with network equipment's TV+, and connect GND terminal with network equipment's TV-
- (4) VCOM,AUDIO+ are three audio ports, it is convenient for user only, you can connect audio wire with VM-03N, also you can select not connect audio wire with VM-03N.



~VM-01T video sender & VM-01R video receiver

- (1) VM-01T video sender: ~ +12V,GND~terminal connect respectively with DC12V power's positive, negative polarity. ~VIDEO,GND~connect with camera; ~VIDEO+,VIDEO-~connect with VM-01R's ~VIDEO+,VIDEO-~
- (2) VM-01R video receiver: ~ +12V,GND~terminal connect respectively with DC12V power's positive, negative polarity. ~VIDEO,GND~connect with CRT or monitor's video input and video GND; ~VIDEO+,VIDEO-~connect with VM-01T's ~VIDEO+,VIDEO-~



Note: there is an electrograph(RV1), switch(SW1) in VM-01R video receiver's electronics board, RV1 is whiteness adjuster, SW1 is color adjuster. Dial SW1 downward to switch it ON, normally, when distance is 500 m, ~1~ is ON, others are OFF; When the distance is 800 m, ~1~,~2~ are ON, others are OFF; when the distance is 1200 m, ~1~,~2~,~3~ are ON, others are OFF; when the distance is 1500 m, the above are ON(~1~,~2~,~3~ are dialing times). Please select accordingly when in actual use, and match RV1 to achieve the best video quality.




Attached supplemental manual for network video door phone's relay equipments

Relay equipment features

- ~VM-03N video amplifier: amplifies the video signal for long distances
- ~VM-01T video sender & VM-01R video receiver: VM-01T is sending and VM-01R is receiving, they must exist at the same time, it mainly solves the long-distance -transferring-signal problem.


Relay equipment technical parameters

~VM-03N video amplifier:



- a)Working voltage: 12V DC~1.1
- b)Standby current: ~15mA
- c)Working current:~120mA

~T·1-VM video sender:



- a)Working voltage:12V DC~1.1
- b)Standby current: ~200mA
- c)Working current:~300mA

~R·1-VM video receiver



- a)Working voltage:12V DC~1.1
- b)Standby current: ~200mA
- c)Working current:~300mA

Relay equipment selection

- ~Selection video relay equipment for network system
- ~When transmitting video signal, if you are using branches, please select the VM-03N video amplifier between the network equipments
- ~When video transmission distance is equal or over 500 M, please select one VM-01T video sender and one VM-01R video receiver between network equipments
- ~When transmitting video signal, if you are using branches and the transmission distance is more than500 M, please select VM-03N video amplifier, one VM-01T video sender and one VM-01R video receiver between network equipments

Contents

1~System introduction	1
2~System Characteristics	1
3~System constitution	1
4~Product structure and functions	2
5~System components and parameters	5
6~System diagram	11-15
1.Non-Network system diagram	11-12
(1)Non-Network video system diagram	11
(2)Non-Network audio system diagram	12
2.Network system diagram	13-14
(1)Network video system diagram	13
(2)Network audio system diagram	14
3.Diagram for main indoor phone CM-02NLRaM	15
7~System Wiring	16-35
1.Non-network wiring for video system	16
2.Non-network wiring for audio system	19
3.Network system wiring	20-35
(1)Network wiring for video system	20
~Wiring between conformity unit and switch	20
~Wiring among switch, door station and module	22
~Wiring between module and indoor phone	26
(2)Network wiring for audio system	31-35
~Wiring between conformity unit and switch	31
~Wiring among switch , module and door station	33
~Wiring between module to indoor phone	35
8~Wiring Instruction	36
9~Wiring Material	40
10~System setting	41
11~System operations	42
12~Installation	46-49
1.Installation size	46
2.Door station's installation and notes	49
13~Instructions for easy malfunction	50
14~Supplemental manual for network relay equipment(attachments)	51

1 System Introduction

- Encode construction, easily installation and debug.
- The indoor phone is installed by hanging up, the door station or the management center can call the indoor phone and can communicate with each other. This system has the functions of alarm and remote control unlock.
- 1/3' CCD used in the door station, and LED enables users to identify visitors clearly even at night.
- The door station has different password for users to unlock the door, three digits or four digits Room No. optional..
- One door station can connect 100 modules. One module can connect 4 indoor phones which can be used in different floors.

2 System Characteristic

- Durable materials have been used to encode a long life time.
- Standby current consumes little electricity, economical electricity.
- Ding Dong or 3 different ring tones available.
- Different models indoor phone are optional.

3 System Combination

Notice: For different purposes, we provide different switches and modules. WL-03NQH-1/2/4 and CM-03NQH-1/2/4 are with iron shell. WL-03NQH1/2-162, CM-03NQH1/2-162, WL-03NQH-216 and CM-03NQH-216 are with plastic shell. They have 1, 2 and 4 route way for consumer's different purposes.

System combination for video system:

- Door station: CM-03NL~CM-03NL-C~CM-03NLA~CM-03NLA-C
- Indoor phone: CM-02NLRG~CM-02NLRG-C~CM-02NLRH~CM-02NLRH-C~CM-02NLRM~CM-02NLRM-C~CM-02NLRM1~CM-02NLRM1-C~CM-02NLRaM~CM-02NLRaM-C~CM-02NLRbM~CM-02NLRbM-C~CM-02NLRi~CM-02NLRj~CM-02NLRv~CM-02NLRv-C
- Module: CM-03NLCH-162 or CM-03NLCH
- Power: PSE~PS-9
- Switch: CM-03NQH-1(1 route way)~CM-03NQH-2(2 route way)~CM-03NQH-4(4 route way)~CM-03NQH1-162(1 route way)~CM-03NQH2-162(2 route way)~CM-03NQH4-216(4 route way)
- Conformity unit: CM-03NZH(1/2/4 route way)(used in network function)
- Management unit: CM-03NHMC(used in network function)
- Wall phone: CM-03NWD(A)(Optional)


System combination for audio system:

- Door station: WL-03NL~WL-03NL-C~WL-03NLA~WL-03NLA-C
- Indoor phone: WL-02NLFD~WL-02NLFH~WL-02NLFC~WL-02NLFH1~WL-02NLFL
- Module: WL-03NLCH
- Power: PSE~PS-5E~PS-9

13 Instructions for easy malfunction

Malfunction phenomenon	Malfunction reason	Solving instructions
Door station doesn't work	Check the system's power supply indicator, see whether it light or not; check the power wire's connection ways, see whether it is right or wrong	If indicator doesn't light, it represent power off, according to correct diagram to connect the power with door station.
All users of whole building can not unlock	Check whether the wire from door station to power and power to electrical lock is correct or not, whether the electrical lock is compatible with the system or not(this system is signal-unlock), whether the door station's bus wire is connected correct or not	Check if there is +12V output power at the LOCK port of the door station when unlock. If there is no power, change the door station. If there is, check if the connection is correct or if there is something wrong with the lock.
The door station cannot call all indoor phones.	Main wires are connected wrong. Short circuit or broken wire.	Correct the connections according to the connection map, and use another good machine to test.
Indoor phones has raster but no picture	If whole building's indoor phone hasn't pictures, Please check whether the wiring from door station video output VIDEO to module video input is divided by negative and positive accordingly or not. If individual indoor phone hasn't pictures, please check whether its video-wiring is correct or not, or the indoor phone is damaged or not. Also please check the video amplifier is power on or off, input and output port is corrected right or not.	Power on the video amplifier, connect the video amplifier's video input and output port correctly with indoor phone and test
Can not network with management unit	If all door stations can not network with management unit, check whether the management unit's bus wire's connection is correct or not, whether the management unit is workable or not; if parts of door stations can not network, please check whether the network port , which is the nearest to the management unit , is damaged or not.	Connect the wires correctly according to diagram, and change a good machine to test
IC/ID card can not unlock	Whether they are registered or not; whether they are damaged or not; whether the reading ways is correct or not; whether the door station is damaged or not	IC/ID card shall be less than 50 mm to sensitive area. If all of cards can not unlock, emphasize checking door station's wiring; if individual card can not unlock, it represent the card isn't registered or canceled record or damaged.

2. Door station's installation and notice:



Iron door
Door station's panel
Door station's back cover
4 M4x45 Screws
Small cover

Installation steps on iron door:

- (1) Drill a rectangular hole on proper position of the iron according to door station installation size.
- (2) Pull out the two small covers. Take off the screws with the attached inner hexagon wrench, and then take off the door station back cover. Fix the back cover on the iron door. Then lock the door station from the back cover with the attached two M4x45 screws and fixed steel sheet.
- (3) Push the small covers and firm it.

Installation steps on wall:

- (1) Drill a rectangular hole on proper position of the wall according to door station installation size.
- (2) Drill four 6mm holes as the door station installation size on the groove. Fix the back cover on the groove with the attached plastic tubes and screws (4.2x40mm).
- (3) Press the front cover on the back cover, then use 2 M4x25 inner hexagon screws to lock them.


Notes

The holes should be drilled according to the size of door station and relative installation size on iron door or wall.
Make sure that when you install the door station that is mounted closely to the door or wall there should be no gap.
Install the door station on the side that usually closed.
Do not install the door station on where it is exposed to direct rain or sunlight.
CM16~CM18: between : Installation height


- (5) Switch WL-03NQH-1(1 route way)~WL-03NQH-2(2 route way)~WL-03NQH-4(4 route way)~WL-03NQH1-162(1 route way)~WL-03NQH2-162(2 route way)~WL-03NQH4-216(4 route way)
- (6) Conformity unit WL-03NZH(1/2/4 route way)(used in network function)
- (7) Management unit WL-03NHMC(used in network function)
- (8) Wall phone WL-03NWD(A)(Optional)

4 Product conformation and function

Door Station




Set chord ring for door station:(only available at the system with Melody ring)




Set: take off the back cover of the door station(as the figure shown) there is a switch. The number(1~3) on the switch stands for one melody ring. When you turn the switch to the one you can choose one of the melody ring.

door station inside

Indoor Phone



Indoor Phone




(5) Module

Model	Size	Installation diagram
WL-03NLCH	86 √ 86 √ mm ± 0	
CM-03NLCH	146 √ 86 √ mm ± 0	

(6) Module and Network switch


Model	Size	Installation diagram (1)
111-NLCH • 3-CM	162 √ 110 √ 45mm	
2-111NQH • 3-CM	162 √ 110 √ 45mm	
3-111NQH • 3-CM	162 √ 110 √ 45mm	
PS-2E	124 √ 90 √ 70.5mm	
PS-5E	124 √ 90 √ 70.5mm	



(3) Installation size and diagram of indoor phones

Model	Size	Installation diagram
CM-02NLRG	205 √ 220 √ 65.5mm	
CM-02NLRH	224 √ 218 √ 59mm	
Model	Size	Installation size
CM-02NLRM	210 √ 220 √ 68mm	
CM-02NLRJ	235 √ 200 √ 48mm	
CM-02NLRJ	292 √ 198 √ 47mm	
CM-02NLRV	250 √ 224 √ 49mm	

Installation diagram:



Installation steps:

screws as the installation^④ Fix the holder on a suitable position on wall with (1) diagram

(2) Hang up the indoor phone on the holder

Note:

.Do not install near moist place and burner(1)

.Do not install near the place where causes strong electronic magnetic field(2)

)Such as TV loudspeaker(3)

Do not fall or punchy strike(4)

.Do not clean by wet cloth or volatile reagent(5)

.because of high voltage inside, Do not dismantle optionally(6)

.Keep the glass of the door station and indoor phone clean(7)

(4) Audio indoor phone

Model	Size	Installation diagram
WL-02NLFD	201 √ 140 √ 67mm	
WL-02NLFH	216 √ 94 √ 59mm	
WL-02NLFC	203 √ 89 √ 64mm	
WL-02NLFH1	220 √ 85.6 √ 49.5mm	
WL-02NLFL	100 √ 210 √ 32.5mm	

Indoor Phone

CM-02NLRJ

CM-02NLRV

① Display screen ⑤ Monitor

② Talk button ⑥ Unlock button

③ Mute button ⑦ Busy Indicator

④ Call button ⑧ Power Indicator

⑨ Talk Indicator ⑬ Contrast button

⑩ Speaker ⑭ Ringing Volume

⑪ Microphone ⑮ Voice volume

⑯ Door panel

Note

③ Mute :mutes the indoor phone's loudspeaker.

CM-02NLRV Indoor Phone

① Display screen ⑤ Silence button

② Monitor button ⑥ Talk button

③ Unlock button ⑦ Speaker

④ Call button ⑧ Talk Indicator

⑨ Power Indicator ⑬ Voice volume

⑩ Brightness button ⑭ Slide cover

⑪ Contrast button

⑫ Ringing Volume

Note

④ Call: (1)To call management unit---first press talk button firstly, then press this button, (2)For emergency call , press this button directly.

⑤ Silence:Mutes the indoor phone' s loudspeaker.

5 System components and parameters:

1. CM-03NL Video Door Station




- a) Working Voltage: $V_{11} \Delta DC \sim 10\%$
- b) Standby Current: $\sim 50mA$
- Working Current: $c: \sim mA \sim \Delta$
- d) (Camera: $\backslash / \sim$ CCD
Viewing angle: 92.8°
Min Luminance: $0.1Lux$
Lens: $F=3.6$
- e) Environment Temperature: $-25^\circ \sim +70^\circ$
- f) Humidity: $45\% \sim 95\%$

2. WL-03NL Audio Door Station



- a) Working Voltage: $12V DC \sim 10\%$
- b) Standby Current: $\sim 75mA$
- c) Working Current: $\sim mA \sim \Delta$
- $\sim \Delta$: -Environment Temperature) d) $+V \sim$
- e) Humidity: $45\% \sim 95\%$

3. Module




112-NLCH-03-CM



NLCH-03-CM

- a) Working Voltage: $18V DC \sim 1.1$
- b) Standby Current: $\sim 8mA$
- c) Working Current: $\sim 170mA$


4. PS-5E Power




- a) AC Input Voltage: $\sim 3V \cdot AC \pm 10\%$
- b) DC Output Voltage: $V_{11} \Delta DC / 800mA$

12 Installation

1. Installation size :) aluminum alloy cover length=L(



Installation size on iron door



Installation size on wall


(1) Installation size table for aluminum alloy door station series

Model	Cover length L(mm)	Door station size(mm)	Installation size on iron door (mm)	Installation size on wall(mm)
NL-03-WL	268	304 $\times$ 111	296) L(111) W(111) D(	214) L(111) W(111) D(
NLA-03-WL	348	384 $\times$ 140 $\times$ 52	376) L(140) W(140) D(	376) L(140) W(140) D(
NL-03-CM	312	348 $\times$ 140 $\times$ 52	340) L(140) W(140) D(	338) L(140) W(140) D(
NLA-03-CM	388	424 $\times$ 130 $\times$ 52	416) L(130) W(130) D(	416) L(130) W(130) D(

(2) Power and CM-03NQH network switch

Model	Size	Installation size:
PS-9	383 $\times$ 181 $\times$ mm	
CM-03NZH(1/2)	383 $\times$ 181 $\times$ mm	
CM-03NQH	240 $\times$ 176 $\times$ 71mm	
PS-2	179 $\times$ 189 $\times$ 70mm	
PS-5A-3	283 $\times$ 189 $\times$ 71mm	

Installation diagram



~Pick up the handset of the ringing phone, you can talk with the calling indoor phone about 120sec. you can also talk with the door station (during this time, you can hear the ~busy line~ indication). When the calling indoor phone hangs up, the called indoor phone can talk with the door station.

~If the system connects with a front door station, the operation is the same with the door station, the only difference is that you have to keep pressing the ~Unlock~ button for more than 3 seconds, otherwise you cannot unlock for visitors.

(2) Surveillance on indoor phone

~Press the ~Monitor~ button, you can monitor the door entry. After 15 seconds, it will be automatically shut down. If you want to quit the surveillance, just press the ~Monitor~ button again.

~If the system connects with a front door station, you can monitor the two door entries circular order. If you want to monitor the main door entry, please press the ~Monitor~ button just one time. If you want to monitor the front door entry, please keep pressing the button more than 2 seconds.

~If there are two or more indoor phones, the system allows only one to surveil the door entry at a time, and the other indoor phones ~Busy~ indicators will lights and cannot call each other during surveillance.

~During monitoring the door station, the main indoor phone can listen in the door station. Press ~Call~ button can talk with the door station and unlock the door.

(3) Broadcasting between the indoor phones

~Pick up the handset, the indoor phone's ~Talk~ indicator will light, press the ~Call~ button for seconds and release, then broadcasting is begin, meanwhile other indoor phone's ~busy~ indicators will flash, and the indoor phones give ring. The broadcasting time is 30 seconds.


~Other hosts can pick up the handsets to answer when they receive the broadcasting. The conversation time is 120 seconds. During the period, the other indoor phones which handsets are not pick up stop ringing automatically, but their ~Busy~ indicators keep lighting. When the broadcasting or conversation time is up, the system will be shut down automatically.

~During intercommucating, if somebody call the door station, the system will switch directly to the talking between the door station and the indoor phone.

(4) Call the management unit from main indoor phone: pick up the main indoor phone's handset, press the ~Management~ button, the management unit rings (you can hear the echo). If nobody answers, the system will be automatically shut down after 30 seconds. **(Remarks: extra indoor phones do not have this function, but the main indoor phone can connect the line to extra indoor phones).**

(5) Main indoor phone alarm: Do not pick up the handset, just press the ~Management~ button, the management unit can receive the alarm message. **(Remarks: this function is only available for the main indoor phone).**

5. CM-02NLRG/CM-02NLRG-C Indoor Phone



- a) Working Voltage: 18V DC ~10%
- b) Standby Current: ~15mA
- c) Working Current: ~50mA
- d) Kinescope: 4' flat tube (B/W) ~ Resolution > 450 lines
- e) Color Display: 4' color LCD display ~ Resolution: 480 ~ 250 points
- f) Environment Temperature: -10 ~ +55 ~
- g) Humidity: 45% ~ 95% ~

6. C Indoor Phone-NLRH • ~CM/NLRH • ~CM



- a) Working Voltage: 18V DC ~10%
- b) Standby Current: ~15mA
- c) Working Current: ~500mA
- d) Kinescope: 4' flat tube (B/W) ~ Resolution > 450 lines
- e) Color Display: 4' color LCD display ~ Resolution: 480 ~ 250 points
- f) Environment Temperature: -10 ~ +55 ~
- g) Humidity: 45% ~ 95% ~

7. C Indoor Phone-NLRM • ~CM/NLRM • ~CM



- a) Working Voltage: 18V DC ~10%
- b) Standby Current: ~15mA
- c) Working Current: ~500mA
- d) Kinescope: 4' flat tube (B/W) ~ Resolution > 450 lines
- e) Color Display: 4' color LCD display ~ Resolution: 480 ~ 250 points
- f) Environment Temperature: -10 ~ +55 ~
- g) Humidity: 45% ~ 95% ~

8. C Main Indoor Phone-NLRaM • ¥-CM/NLRaM • ¥-CM




- a) Working Voltage: 18V DC ~10%
- B) Standby Current: ~90mA
- c) Working Current: ~83mA •
- d) Kinescope: 4" flat tube (B/W) • Resolution > 450 lines •
- e) Color Display: 4" color LCD display •
Resolution: 480 ~ 250 points •
- f) Environment Temperature: -10 ~ +55 • •
- g) Humidity: 45% ~ 95% •

9. C Extra Indoor Phone-NLRbM • ¥-CM/NLRbM • ¥-CM



- a) Working Voltage: 18V DC ~10%
- b) Standby Current: ~90mA
- c) Working Current: ~830mA
- d) Kinescope: 4" flat tube (B/W) • Resolution > 450 lines •
- e) Color Display: 4" color LCD display •
Resolution: 480 ~ 250 points;
- f) Environment Temperature: -10 ~ +55 • •
- g) Humidity: 45% ~ 95% •

10. Free Indoor Phone-NLRI Hands • ¥-CM



- a) Working Voltage: 18V DC ~10%
- b) Standby Current: ~15mA
- c) Working Current: ~50mA •
- d) Color Display: 4" or 5.6" color LCD display •
Resolution: 480 ~ 250 points
- e) Environment Temperature: -10 ~ +55 • •
- f) Humidity: 45% ~ 95% •

(3) **Door station call indoor phone in the same building:** press ~*~ and input the room No. that's all. For example: If you want to call NO. 102 family, when room number is three digits: press Room No. ~102~; When room number is four digits, press Room No. ~0102~. If the Room No. is right, the indoor phone will ring, the host can pick up the handset (if for handfree indoor phone, press button ~TALK~) to talk with the visitor. And the conversation time limit is 120 seconds. When time is up, the door station will switch off automatically, if you want to continue talking, please call again. If nobody answers the indoor phone, the door station (with ring) begin to count down 30 seconds and after 30 seconds, the door station will shut down automatically. If you input the wrong room number, the door station will display ~Err~ and shut down automatically.

Note: The following functions only come into effect when in the network system.

(4) **Calling from door station to management unit:** just press the ~Management Unit No.~ on the door station, for example, if you want to call No.01 Management Unit, just press ~* + 01 + #~, (if the room number is just 2 digital, you just need dial ~* + # + 01~ to call management unit by door station), the Management Unit will ring, person in charge of the Management Unit can answer the phone, the conversation time limit is 120 seconds. If nobody answers the phone or the line is busy, the management unit will quit in 30 seconds. The management unit can unlock the door for the ~Called~ door station.

(5) **Indoor phone calls management unit:** pick up the handset of the indoor phone (if for handfree indoor phone, press button ~TALK~) and press ~ of ~CALL~ button, the management unit will ring, person in charge of the management unit can answer the phone. If nobody answers the phone or the line is busy, the management unit will quit in 30 seconds.

(6) **Indoor phone call for help:** press ~ of ~CALL~ button, the management unit will receive the help message.

Note: when debugging, if there are more than one same room numbers in one system, you can not call the indoor phone.

3.CM-02NLRaM/02NLRbM Video indoor phone operation

(1) Call from door station:

~Press the room number button on the door station, all of the indoor phones in the room ring, meanwhile the screens display the visitor's image, and the ~Busy~ indicators flash. If nobody answers, the system will be automatically shut down after 30 seconds.

~Pick up the handset and talk with the visitor (at the moment, the ~Talk~ indicator lights). The other indoor phones will be shut down and the ~Busy~ indicators will keep lighting. During the conversation, press the ~Unlock~ button, you can unlock for the visitor.

~If you want to connect the line to another indoor phone when you are talking with the visitor, just press the ~Call~ button, then the other indoor phones will ring, meanwhile the door station gives voice.

(4)**Monitor function:** press the "Monitor" button in the indoor phone, you can see the condition outside door for 15 seconds. If you want to cancel the monitor, just press the "Monitor" button again. (Note: If somebody calls another indoor phone at this time, the monitor function will be off.)

Note: The following functions only comes into effect when in the network system.

(5)**Calling from door station to management unit:** just press the "Management Unit No." on the door station, for example, if you want to call No.01 Management Unit, just press "* + 01 + #", (if the room number is just 2 digital, you just need dial "* + # + 01 to call management unit by door station), the Management Unit will ring, person in charge of the Management Unit can answer the phone, the conversation time limit is 120 seconds. If nobody answers the phone or the line is busy, the management unit will quit in 30 seconds. The management unit can unlock the door for the "Called" door station.

(6)**Indoor phone calls management unit:** pick up the handset, press "Call" button, the management unit will ring, person in charge of the management unit can answer the phone. If nobody answers the phone or the line is busy, the management unit will quit in 30 seconds.

(7)**Indoor phone call for help:** press "Call" button, the management unit will receive the help message.

Note: when debugging, if there are more than one same room numbers in one system, you can not call the indoor phone.


2. Audio system operation:

(1)**Password to unlock the door station:** Press "* + F4", the door station will display "Addr", enter the room No.(3-digit or 4-digit), If the door station displays "Pd-p", Please enter password (the default password is 1234), Then the door station displays "Pass" indicates successful unlock. If enter the wrong room number, the door station will display "Err" and shut down automatically. If you enter the wrong unlock password, the door station will display "Pd-p". If you enter wrong unlock password more than five times at the same time, the door station will shut down automatically.

(Note: when the system operate in a network if users key a wrong password more than 5 times at one time. then the door station will give an alarm to the management unit automatically

(2)**Change unlock password:** Press "* + 3 + F3", the door station displays "Addr", enter the room No. (3-digit or 4-digit), door station displays "Pd-p", enter old unlock password, then door station displays "Pd-n", please enter new password, If the door station displays "Pass", which indicates the unlock password successful change. If you enter the wrong room NO and password, the door station will display "Err" and shut down automatically.

11. Free Indoor Phone-NLRJ Hands • ¥-CM




- a) Working Voltage: 18V DC ± 10%
- b) Standby Current: 15mA
- c) Working Current: 90mA
- d) Color Display: 4" or 5.6" color LCD display
Resolution: 480 × 250 points
- e) Environment Temperature: -10° ~ +55°
- f) Humidity: 45% ~ 95%

12. Free Indoor Phone-C Hands-NLRV • ¥-CM/NLRV • ¥-CM




- a) Working Voltage: 18V DC ± 10%
- b) Standby Current: 15mA
- c) Working Current: 500mA
- d) Kinescope: 4" flat tube (black/white)
- e) Color Display: 4" color LCD display
Resolution: 480 × 250 points
- f) Environment Temperature: -10° ~ +55°
- g) Humidity: 45% ~ 95%

13. Network Switch For Video System




CM-03NQH2-162



CM-03NQH

- a) Working Voltage: 18V DC ± 10%
- b) Standby Current: mA
- c) Working Current: mA

14. PS-9 Power(UPS)



- a) AC Input Voltage: 130V ~ 270V AC ± 10%
- b) DC Output Voltage: 12V / 5V

15. CM-03NZH Conformity Unit(4 route way)



- a) Working Voltage: $V_{DC}^{12 \sim 14}$
 $V_{DC}^{6 \sim 14}$
- b) Standby Current: $\sim 85mA$
- c) Working Current: $\sim 500mA$

16. CM-03NHMC Management Unit




- a) Working Voltage: $18V_{DC} \sim 10\%$
- b) Standby Current: $\sim 120mA$
- c) Working Current: $\sim 800mA$

17. CM-03NWD(A) Wall Phone




- a) Working Voltage: $18V_{DC} \sim 10\%$
- b) Standby Current: $\sim 75mA$
- c) Working Current: $\sim 350mA$

18. Network Switch For Audio system



WL-03NQH2-162




WL-03NQH

- a) Working Voltage: $12V_{DC} \sim 10\%$
- b) Standby Current: $\sim 5mA$
- c) Working Current: $\sim 1mA \dots$

3. How to adjust the tones (Uncover the door station.)

(L

tone with the four holes.



- Position 1 Adjuster for the door station speech volume
- position 2 Adjuster for the indoor phone ring volume
- position 3 Adjuster for the indoor phone speech volume
- position 4 Adjuster for the door station feed-back ring volume

The back cover of the door station

11 System operation

1. Video system operation :


- (1) **Password to unlock the door station:** Press $\sim * + F4 \sim$, the door station will display $\sim Addr \sim$, input the room No. (3-digit or 4-digit), If the door station displays $\sim Pd-p \sim$, Please input password (the initialization password is 1234), Then the door station displays $\sim Pass \sim$ indicates successful unlock. If input the wrong room number, the door station will display $\sim Err \sim$ and shut down automatically. If you input the wrong unlock password, the door station will display $\sim Pd-p \sim$. If you input wrong unlock password more than five times at the same time, the door station will shut down automatically.

(Note: when the system operate in a network if users key a wrong password more than 5 times at one time. then the door station will give an alarm to the management unit automatically)

- (2) **Change unlock password:** Put the $\sim Jb1 \sim$ in the module to the $\sim SET \sim$ position press $\sim * + 3 + F3 \sim$, the door station displays $\sim Addr \sim$, input the room No. (3-digit or 4-digit), door station displays $\sim Pd-p \sim$, input old unlock password, then door station displays $\sim Pd-n \sim$, please input new password, If the door station displays $\sim Pass \sim$, which indicates the unlock password successful change. If you input the wrong room NO and password, the door station will display $\sim Err \sim$ and shut down automatically. When finished the setting, put the $\sim JB1 \sim$ in the module to the $\sim COM \sim$ position.

- (3) **(Door station call indoor phone in the same building:** press $\sim * \sim$ and input the room No. that's all. For example: If you want to call NO. 102 family, when room number is three digits: press Room No. $\sim 102 \sim$; When room number is four digits, press Room No. $\sim 0102 \sim$ If the Room No. is right, the indoor phone will ring, the host can pick up the handset to talk with the visitor. And the conversation time limit is 120 seconds. When time is up, the door station will switch off automatically, if you want to continue talking, please call again. If nobody answer the indoor phone, the door station (with ring) begin to count down 30 seconds and after 30 seconds', the door station will shut down automatically. If you input the wrong room number, the door station will display $\sim Err \sim$ and shut down automatically.

10 System setting(video/audio system are same)



1.Set door station No.: Put the JB1 in the network switch to SET position. Press *+1+F3, the door station shows Addr, input door station No., You can hear a suggestive sound of du, it means the setting is ok. When finish setting, put the JB1 in the network switch to COM position. Commonly the door station No. is 4- digit number, If the number with letters, One letter is equal to two digits, such as 0008, 02B. (Note: This only need to set when in network system, and its function only become effective in the NETWORK system).

2.Set Room No.: uncover the module, put the module's pin cap at SET position then lightly poke the SETUP hole on the surface of module with a ball pen, the module's indicator flickers quickly, the door station will display Addr, type 3-digit or 4-digit room No. on the door station, (the Room No. is decided by the door station) and the door station will display Port, then enter one module terminal number(one digit number from 1-4), if door station displays Addr again, that indicates the room No. has been set, you can continue to type the next room No., If door station displays Err and then Addr, that means you failed to set the room NO., re-enter again. When finished room number setting, press SET button on the module, if the indicate light is flickering slower, then you can quit the setting. Put the pin cap to the COM position to avoid the losing of the room number. (Please note: one module can set 4 room numbers at most, all initialization unlock passwords are 1234.)

For example: If set Room No. 101, operate as below, Press SET button on the surface of the module which the indoor phone 101 connects to, the indicator will flicker quickly, the door station will display Addr Input 0101; the door station will display Port Input Port No. 1 which the indoor phone connects to accordingly, the door station will display 1 first then Addr, this means setting successfully. Press SET button, the indicate light is flickering slower, which means you are quitting the setting.

Note: when set user number in the module, connect one module with door station, set room numbers follows above, after finishing, take away the IC memory (U3, it is used to memorize the set room info) and mark it (the port and its number). Then insert another IC memory to this module and follow above instruction one by one until you finish all room number. Then insert the set IC memory into modules of the corresponding floors. It is the most efficient way to set room number.

19. Audio Indoor Phone



- a) Working Voltage: DC12V $\sim$ 10%
- b) Static Current: 0
- c) Working Current: $\sim$ 2mA




20. WL-02NLFL Audio Indoor Phone




- a) Working Voltage: DC12V $\sim$ 10%
- b) Static Current: $\sim$ 20mA
- c) Working Current: $\sim$ 6mA

21. PS-2E Power



- a) AC Input Voltage: $\sqrt{\text{AC}3\text{V} \cdot \begin{matrix} +10\% \\ -15\% \end{matrix}}$
- b) DC Output Voltage: $\sqrt{\text{DC}3.5\text{V}/800\text{mA}}$

22. WL-03NLCH Module



- a) Working Voltage: DC12V $\sim$ 10%
- b) Static Current: $\sim$ 8mA
- c) Working Current: $\sim$ 25mA

23. WL-03NZH Conformity Unit(4 routeway)




- a) Working Voltage: $\sqrt{\text{DC} \cdot \begin{matrix} 1 \cdot 1 \\ 1 \cdot 1 \end{matrix}}$
- b) Static Current: $\sim$ 85mA
- c) Working Current: $\sim$ 400mA

Note: above $\sqrt{}$ partial explanation and input voltage, the voltage can be set according to different region countries.

6 System diagram

1.Non-Network system diagram

(1)Non-Network video system diagram



9 Wiring Material

Model	Diagram		Wire material requirements(vertical square)		Remarks	
Video system	Between door station and module		▽ 30M RVV6 ▽ 0.75mm ² SYV75-5/96 PCS ▽	▽ 100M RVV6 ▽ 1.5mm ² SYV75-5/96 PCS ▽	(2)Actual wire depended on capacity of the project! When exceed the ordered distance, please enlarge the square accordingly (3)when network, if the total distance is exceed 200M, please add one video amplifier and repeaters. (4)the parameter in this chart is only for reference, our company reserve the right to change and explain.	
	Between module and indoor phone	Hand-set indoor phone	▽ 30M RVV4 ▽ 0.5mm ² +SYV75-5/96	▽ 100M RVV4 ▽ 1.5mm ² +SYV75-5/96		
		Hand-free indoor phone	RVV6 ▽ 0.75mm ² +SYV75-5/96	RVV6 ▽ 1.5mm ² +SYV75-5/96		
		Between door station and power supply		▽ 10M RVV2 ▽ 1.0mm ²		
	Between door station and electrical lock		▽ 10M RVV2 ▽ 1.0mm ²			
	Among switch , door station and module		▽ 100M RVVP6 ▽ 0.75mm ² SYV75-5/96 PCS ▽	▽ 200M RVVP6 ▽ 1.0mm ² SYV75-5/96 PCS ▽		
			Between Conformity unit and management unit			▽ 800M RVVP5 ▽ 1.0mm ² SYV75-7/128 PCS ▽
			Between Network switch and Conformity unit's BUS board			When 4 rout waysLRVP11*1.0mm +4 video wires SYV75-7/128)three wires are data wire and eight wires are audio wire in the 11-core wire(When 3 rout waysLRVP9*1.0mm +3 video wires SYV75-7/128)three wires are data wire and six wires are audio wire in the 9-core wire(When 2 rout waysLRVP7*1.0mm +2 video wires SYV75-7/128)three wires are data wire and four wires are audio wire in the 7-core wire(When 1 rout waysLRVP5*1.0mm +1 video wires SYV75-7/128)three wires are data wire and two wires are audio wire in the 5-core wire(
	Audio system	Between door station and module		▽ 30M RVV4 ▽ 0.5mm ²		▽ 100M RVV4 ▽ 1.0mm ²
		Between module and indoor phone	Hand-set indoor phone	▽ 30M RVV2 ▽ 0.3mm ²		▽ 100M RVV2 ▽ 1.0mm ²
			Hand-free indoor phone	RVV4 ▽ 0.3mm ²		RVV4 ▽ 1.0mm ²
			Among switch , door station and module			▽ 100M RVVP4 ▽ 0.75mm ²
		Between conformity and management unit				▽ 800M RVVP5 ▽ 1.0mm ²
Between Network switch and Conformity unit's BUS board		When 4 rout waysLRVP11*1.0mm shield wire(three wires are data wire and eight wires are audio wire in the 11-core wire) When 3 rout waysLRVP9*1.0mm shield wire)three wires are data wire and six wires are audio wire in the 9-core wire(When 2 rout waysLRVP7*1.0mm shield wire)three wires are data wire and four wires are audio wire in the 7-core wire(When 1 rout waysLRVP5*1.0mm shield wire)three wires are data wire and two wires are audio wire in the 5-core wire(				

(2)Wiring between switches and among switch, door station, module, and conformity unit:

Wiring among switches:

Network Switch	Data A	Data B	Common terminal	Audio input for No.1 route way	Audio GND input for No.1 route way	Audio input for No.2 route way	Audio GND input for No.2 route way	...
	LA	LB	COM	AI1+	AI1-	AI2+	AI2-	...
	↕	↕	↕	↕	↕	↕	↕	↕
Network Switch	Data A	Data B	Common terminal	Audio output for No.1 route way	Audio GND output for No.1 route way	Audio output for No.2 route way	Audio GND output for No.2 route way	...
	LA	LB	COM	AO1+	AO1-	AO2+	AO2-	...

Wiring between switch and door station, module:

Door Station	Audio power	Audio	Data	Audio GND
	POWER	AF	DATA	GND
	↕	↕	↕	↕
Network Switch	Audio power	Audio	Data	Audio GND
	POWER	AF	DATA	GND
	↕	↕	↕	↕
Module	Audio power	Audio	Data	Audio GND
	VCC	AF	DATA	GND

Wiring between switch and extra door station:

Extra Door Station	Audio	Data	Audio GND
	AF	DATA	GND
	↕	↕	↕
Network Switch	Audio	Data	Audio GND
	AF	DATA	GND


Wiring between switch and conformity unit (BUS board):

Network Switch	Data A	Data B	Common terminal	Audio input for No.1 route way	Audio GND input for No.1 route way	Audio input for No.2 route way	Audio GND input for No.2 route way	...
	LA	LB	COM	AI1+	AI1-	AI2+	AI2-	...
	↕	↕	↕	↕	↕	↕	↕	↕
Conformity unit's BUS board	Data A	Data B	Common terminal	Audio for No.1 route way	Audio GND for No.1 route way	Audio for No.2 route way	Audio GND for No.2 route way	...
	LA	LB	COM	AF1+	AF1-	AF2+	AF2-	...

(3)Wiring between conformity unit's PORT board and management unit:


Conformity unit's PORT board	Data A	Data B	Common terminal	Audio	Audio GND
	LA	LB	COM	AF+	AF-
	↕	↕	↕	↕	↕
Management unit's switch box	Data A	Data B	Common terminal	Audio	Audio GND
	OR	BK	BL	GR	YL

(2)Non-Network audio system diagram



2. Network system diagram

(1) Network video system diagram



~Wiring among network switches:

Network Switch	Data A	Data B	Common terminal	Audio input for No.1 route way	Audio GND input for No.1 route way	Video input for No.1 route way	Video GND input for No.1 route way	...
	LA	LB	COM	AI1+	AI1-	VI1+	VI1-	...
	↕	↕	↕	↕	↕	↕	↕	↕
Network Switch	Data A	Data B	Common terminal	Audio output for No.1 route way	Audio GND output for No.1 route way	Video output for No.1 route way	Video GND output for No.1 route way	...
	LA	LB	COM	AO1+	AO1-	VO1+	VO1-	...

~Wiring between switch and conformity unit (BUS board):

Network Switch	Data A	Data B	Common terminal	Audio input for No.1 route way	Audio GND input for No.1 route way	Video input for No.1 route way	Video GND input for No.1 route way	...
	LA	LB	COM	AI1+	AI1-	VI1+	VI1-	...
	↕	↕	↕	↕	↕	↕	↕	↕
Conformity unit's BUS board	Data A	Data B	Common terminal	Audio for No.1 route way	Audio GND for No.1 route way	Video for No.1 route way	Video GND for No.1 route way	...
	LA	LB	COM	AF1+	AF1-	TV1+	TV1-	...

(5) Wiring between conformity unit's PORT board and management unit:

Conformity unit's port board	Data A	Data B	Common terminal	Audio	Audio GND	Video	Video GND
	LA	LB	COM	AF+	AF-	TV+	TV-
	↕	↕	↕	↕	↕	↕	↕
Management unit's switch box	Data A	Data B	Common terminal	Audio	Audio GND	Management unit's video port	
	OR	BK	BL	GR	YL		

2. Audio system:

(1) Wiring between door station and module

Door Station	Audio power	Audio	Data	Audio GND
	POWER	AF	DATA	AGND
	↕	↕	↕	↕
Module	Audio power	Audio	Data	Audio GND
	VCC	AF	DATA	GND

(2) Wiring between module and WL-02NLFL indoor phone

Module	Audio power	Audio GND	Audio	Audio control GND
	VCC	GND	T&R	G1-G4
	↕	↕	↕	↕
Indoor phone	Audio power	Audio GND	Audio	Audio control GND
	+12V	GND	T&R	AGND

Module	Audio	Monitor	Audio control GND	Video Power	Video GND	Video	Audio Power	Audio GND
	T&R	MONI	AGND	V+18V	VGND	TV	A+18V	GND
↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕								
Indoor Phone	Audio	Monitor	Audio control GND	Video Power	Video GND	Video	Audio Power	Audio GND
	T&R	MONI	AGND	V+18V	VGND	TV	A+18V	GND


Module	Audio	Monitor	Audio control GND	Video Power	Video GND	Video	Audio Power	Audio GND
	T&R	MONI	AGND	V+18V	VGND	TV	A+18V	GND
	↕	↕	↕	↕	↕	↕	↕	↕
Indoor Phone	1 (T&R)		2 (AGND)	Two wires from indoor phone, non polarity			+12V	GND
							For WL-02NLFL	
Note: WL-02NLFL indoor phones have to use four-cord cables (T&R/AGND/V+12V /GND) while the other indoor phones use two-cord cables(T&R/AGND).								

Door Station	Audio Power	Audio	Data	Audio GND	Monitor	Video Power	Video GND	Video
	POWER	AF	DATA	AGND	MONI	+18V	TV-	TV+
$\updownarrow$		$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$
Network Switch	Audio Power	Audio	Data	Audio GND	Monitor	Video Power	Video GND	Video
	POWER	AF	DATA	GND	MONI	+18V	TV-	TV+
$\updownarrow$		$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$	$\updownarrow$
Module	Audio Power	Audio	Data	Audio GND	Monitor	Video Power	Video GND	Video
	A+18V	AFIN	DATA	AGND	MONI	V+18V	VGND	TVIN

Extra Door Station	Audio Power	Audio	Data	Audio GND	Monitor	Video Power	Video GND	Video
	POWER	AF	DATA	AGND	MONI	+18V	TV-	TV+
↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕								
Network Switch	Empty	Audio	Data	Audio GND	Empty	Video Power	Video GND	Video
		AF	DATA	GND		+18V	TV-	TV+

[illegible]

3. Diagram for main indoor phone CM-02NLRaM



8~Wiring Instruction

1. Wiring Instruction for video system

(1) Wiring Instruction among door station, power and lock:

Door Station	Audio power	Audio GND power		Electrical Lock	Electrical Lock
	POWER	GND		LK-	LK+

(2) Wiring instruction from door station to module

Door Station	Audio power	Audio	Data	Audio GND	Monitor	Video power	Video GND	Video
	POWER	AF	DATA	GND	MONI	+18V	TV-	TV+
↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕								
Module	Audio power	Audio	Data	Audio GND	Monitor	Video power	Video GND	Video
	A+18V	AFIN	DATA	AGND	MONI	V+18V	VGND	TVIN

(3) Wiring instruction from module to indoor phone


~ Wiring instruction from module to indoor phone CM-02NLRGL

Module	Audio	Monitor	Audio control GND	Video Power	Video GND	Video	Audio Power	Audio GND
	T&R	MONI	AGND	V+18V	VGND	TV	A+18V	GND
↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕								
Indoor Phone	Audio	Monitor	Audio control GND	Video Power	Video GND	Video	Empty	
	T&R	MONI	AGND	+18V	VGND	TV		
	1	2	3	4	5~6	7		

~ Wiring instruction from module to indoor phone CM-02NLRH/CM-02NLRML

Module	Audio	Monitor	Audio control GND	Video Power	Video GND	Video	Audio Power	Audio GND
	T&R	MONI	AGND	V+18V	VGND	TV	A+18V	GND
↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕ ↕								
Indoor Phone	Audio	Monitor	Audio control GND	Video Power	Video GND	Video	Empty	
	T&R	MONI	AGND	V+18V	VGND	TV		


Wiring between module and indoor phone




System Wiring

1. Non network wiring for video system:


(1) Video system-1(module CM-03NLCH-162)



(2)Video system-2(module CM-03NLCH-162)L



b)Wiring among WL-03NQH switch, WL-03NLCH module and door station:




Note

Wires between network switches :the audio output(AO) of the first network switch are connected with the corresponding audio input(AI) of the next network switch. The data wire COM~LA~LB should be connected accordingly.

Wiring among switch , module and door station:


a)Wiring among WL-03NQH2-162 switch, WL-03NLCH-162 module and door station:




Note

Wires between network switches :the audio output(AO) of the first network switch are connected with the corresponding audio input(AI) of the next network switch. The data wire COM*LA*LB should be connected accordingly.


(3)Video system-3(module CM-03NLCH)L



2.Non network wiring for audio system




b)Wiring between conformity unit and WL-03NQH switch (2 route ways):



(2) Network wiring for audio system

Wiring between conformity unit and switch:

a) Wiring between conformity unit and CM-03NQH2-162 switch (2 route ways):




3. Network system wiring

(1) Network wiring for video system

Wiring between conformity unit and switch:

a) Wiring between conformity unit and CM-03NQH2-162 switch (2 route ways):




PS-9 Power


To NL series management unit or wall phone

Note: The conformity unit's main board is made out of 8 BUS and PORT boards. The switch is one, two or four route way. The bus wires quantity depends on the amount of BUS boards and wall phones. The management unit's connects to PORT quantity of wires on the PORT board. One BUS board supports 4 outputs at most. over 200m one BUS board can maximally support 32 switches, if there is no relay equipment. One PORT board can connect with only one management unit or only wall phone. The conformity unit cost depends on the quantity of BUS and PORT boards used.


b)Wiring between conformity unit and NQH·V-CM switch (4 route ways):



e)Wiring between CM-03NLCH module and CM-02NLRaM main indoor phoneL




d)Wiring between CM-03NLCH-162module and CM-02NLRaM main indoor phone



Wiring among switch , module and door station:


a)Wiring among CM-03NQH2-162 switch, CM-03NLCH-162 module and door station:



Note

Wires between network switches :the audio output(AO) and video output(VO) of the first network switch are connected with the corresponding audio input(AI) and video input(VI) of the next network switch. The data wire COM*LA*LB should be connected accordingly.


b)Wiring among CM-03NQH switch,CM-03NLCH module and door stationL




NoteL

Wires between network switches :the audio output(AO) and video output(VO) of the first network switch are connected with the corresponding audio input(AI) and video input(VI) of the next network switch. The data wire COM`LA`LB should be connected accordingly.


c)Wiring between CM-03NLCH module and indoor phoneL



b)Wiring between CM-03NLCH-162 module and indoor phoneL




c)Wiring among CM-03NQH switch,CM-03NLCH-162 module and door stationL



Wires between network switches :the audio output(AO) and video output(VO) of the first network switch are connected with the corresponding audio input(AI) and video input(VI) of the next network switch. The data wire COM'LA'LB sho

Note: The general wiring should be done with loose wires. If you can not use a cable but only loose wires, then you need a repeater. If the distance is less than 100 meters, (if it is more than 100 meters you will need a repeater) one network switch can connect with 100 modules, and one module can connect with 4 indoor phones.

d)Wiring among CM-03NQH2-162 switch,CM-03NLCH module and door station



Note

Wires between network switches :the audio output(AO) and video output(VO) of the first network switch are connected with the corresponding audio input(AI) and video input(VI) of the next network switch. The data wire COM*LA*LB should be connected accordingly.

Wiring between module and indoor phone

a)Wiring between CM-03NLCH-162 module and indoor phone

